TOSHIBA



1-phase 200V 0.2kW to 2.2kW 3-phase 200V 0.2kW to 15kW 3-phase 400V 0.75kW to 15kW



Environment-friendly, Handy Inverter — All Models, EMI Noise Filter Inside

Introducing the New-Generation Compact Inverter! Easy to Use, Powerful Performance, and Wide Applications



Major World Standard







Complies with major world standards (CE marking, UL, cUL, C-tick) (C-tick is under application).

ISO 9001:

VF-S9 series is manufactured at the works, which has received the international quality assurance standard ISO 9001 certification.



The works producing the VF-S9 series is registered as an environment management system factory specified by ISO 14001.






For System Designers ...

Flexible Selections

Excellent basic performance and diverse functions allow operations as needed.

- Sensorless vector control provides the startup torque of 150% or more.
 - The "Auto-tuning function" allows setting motor constants without rotating the motor.
- Wide capacity range (0.2 to 15 kW) is provided even for this compact class.
- Compatible with various power voltages.
 The single-phase input model inputs 200V to 240V, the three-phase 400V model inputs 380V to 500V.
- The control circuit I/O logic (Sink/Source) is switched by one-touch operation. Many types of programmable controllers are easily connected.



■Capacity Range

Voltage Class	Applicable Motor Capacity (kW)										
(Input/Rated Output)	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	
1ø200V/3ø200V											
3ø200V/3ø200V											
3ø400V/3ø400V											




For Manufacturers ...

Easy Installation

EMI noise, audible noise, and installation space problems are solved.

- All models have EMI noise filter inside, significantly reducing noise emissions.
- EMC plate (attached as standard) shields the wiring to further suppress radiated EMI noise.
- Side-by-side installation saves space. Multiple units can be installed without side clearance. For example, installing five units of VFS9-2007PM side by side requires only 60% of the area for conventional inverters.
- Optional DIN rail kit allows one-touch installation (models of 200V class 0.75kW or less).
- Availability of high carrier frequency setting reduces audible motor noise.
 - Even if the carrier frequency is set to a low level to suppress the EMI noise influence, the newly developed "Random Mode Carrier Frequency" can soften audible noise.
- Foot-mount type filter for space-saving is provided as option to comply with the EN standard.





■ Side-by-side installation



3

For Users ...

Easy Setting

Users can easily make settings and operate reliably.

- Switches and potentiometer dial on the front panel allow immediate and easy operation.
- The enhanced "Automatic Setting Functions" enable easy and convenient set up.
 - Automatic acceleration/deceleration, Automatic torque boost, Automatic environment setting, Automatic function setting, reduce start up time.
- Diverse functions are conveniently enhanced.
 - Relay contact output:
 - 1 c-contact + 1 a-contact (+ 1 open collector output) is provided.
 - Programmable I/O terminals:
 - 6 input terminals and 3 output terminals can be selected from 51 input types and 30 output types of menus.
 - Meter analog output:

Analog output signal can be selected from 6 types of menus. 0-10V and 4-20mA signal can also be switched by one-touch operation.

- Enhanced protective functions assure reliable operation.
 - I/O phase failure detecting, earth fault detecting function.
 - Dependable operation in case of power voltage drop.
 - Reliable continuous operation secured by auto-restart control function and regenerative power ride-through control function.

Installation of VF-S9


Conventional models




Contents

Panel and Operation Method 3-
Standard Specifications and External Dimensions
Functional Description 7-
Connection Diagram and Selection of Wiring Devices
Terminal Functions 10
Inverter Q & A 11-13
To Users of Our Inverters 14-1
Peripheral Devices 17-2
Trip Display and Alarm Display 2

Panel and Operation Method





Monitoring — Status monitor mode


In this mode, you can monitor the operational status of the inverter. To display the operation status during normal operation: Press the (MON) key twice.

Setting procedure (eg. operation at 60Hz)

ltem displayed	Key operated	LED display	Description						
		60.0	The operation frequency is displayed (during operation). (When the standard monitor display selection parameter						
Parameter setting mode	MON	AU I	The first basic parameter "Automatic acceleration/deceleration ()" is displayed.						
Operation frequency	MON	F60.0	The operation frequency is displayed (during operation).						
Direction of rotation	(A)	Fr-F	The direction of rotation is displayed. (F: forward run, r: reverse run)						
Operation frequency command	(A)	F60.0	The operation frequency command value is displayed.						
Load current		C80	The inverter output current (load current) is displayed						
Input voltage	(A)	y 100	The inverter input voltage is displayed. (Default setting: unit %)						
Output voltage	(A)	P 100	The inverter output voltage is displayed. (Default setting: unit %)						
Input terminal	•	Attiti	The ON/OFF status of each of the control signal input terminals (F, R, RST, S1, S2 and S3) is displayed in bits. ON: OFF: S3 S2 R RST						
Output terminal	•	0111	The ON/OFF status of each of the control signal output terminals (RY, OUT and FL) is displayed in bits. ON: OFF: RY OUT						

ltem displayed	Key operated	LED display	Description					
CPU version	(A)	u 10 1	The version of the CPU is displayed.					
Memory version	(A)	υΕ 100	The version of the memory mounted is displayed.					
Past trip 1	(A)	OC3 ⇔ 1	Past trip 1 (displayed alternately at 0.5-sec. intervals)					
Past trip 2	(A)	0H ⇔2	Past trip 2 (displayed alternately at 0.5-sec. intervals)					
Past trip 3	(A)	<i>0P3</i> ⇔3	Past trip 3 (displayed alternately at 0.5-sec. intervals)					
Past trip 4	(A)	nErr⇔4	Past trip 4 (displayed alternately at 0.5-sec. intervals)					
Cumulative operation time	(A)	E 0.10	The cumulative operation time is displayed. (0.01 corresponds to 1 hours.)					
Torque current	(A)	L88	The torque current is displayed in %.					
PI feedback	(A)	aso	The PI feedback value is displayed. (Unit: processed amount)					
Inverter load factor	(A)	L 80	The inverter load factor is displayed in %.					
PBR overload factor	(A)	r 80	The overload factor of the braking resistor is displayed in %.					
Output power	(A)	н 3.7	The inverter output power is displayed in %.					
Default display mode	(MON)	600	The operation frequency is displayed (during operation).					

Note) 1. With the current unit selection parameter or voltage unit selection parameter, you can choose between percentage and ampere (A) for current or between percentage and volt (V) for voltage, respectively.



Note) 1. L:Standard model without optional filter conform to "EN55011 Group 1 Class A"
With Foot-mounted noise filter conform to "EN55011 Group 1 Class B"
M:With Foot-mounted noise filter conform to "EN55011 Group 1 Class A"

Note) 2. Interface logic can be switched easily.

Standard Specifications and External Dimensions


■ Model and standard specifications

	Item					Specif	ication						
Input	voltage	3-phase 200V											
Appli	cable motor (kW)	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15		
	Туре					VFS	89 –						
	Form	2002PM	2004PM	2007PM	2015PM	2022PM	2037PM	2055PL	2075PL	2110PM	2150PM		
	Capacity (kVA) Note 1)	0.6	1.3	1.8	3.0	4.2	6.7	10	13	21	25		
Rating	Rated output current (A) Note 2)	1.5 (1.5)	3.3 (3.3)	4.8 (4.4)	7.8 (7.5)	11.0 (10.0)	17.5 (16.5)	27.5 25.0	33 (33)	54 (49)	66 (60)		
	Rated output voltage Note 3)	3-phase 200V to 230V											
	Overload current rating	60 seconds at 150%, 0.5 seconds at 200%											
Power supply	Voltage-frequency				3-pl	nase 200V to	230V - 50/6	OHz					
Po Sup	Allowable fluctuation				Voltage -	+10%, -15%	Note 4), freque	ncy ±5%					
Prote	ective method				IP	20 Enclosed t	ype (JEM103	O)					
Cool	Cooling method					F	orced air-coole	ed					
Colo	r					Munsel 5	5Y-8/0.5						
Built-	in filter			Standard	EMI filter			High-attenua	tion EMI filter	Standard	EMI filter		

	Item						8	Specificatio	n					
Input	voltage	1-phase 200V					3-phase 400V							
Appli	cable motor (kW)	0.2	0.4	0.75	1.5	2.2	0.75	1.5	2.2	3.7	5.5	7.5	11	15
	Туре			VFS9S -						VFS	9 –			
	Form	2002PL	2004PL	2007PL	2015PL	2022PL	4007PL	4015PL	4022PL	4037PL	4055PL	4075PL	4110PL	4150PL
	Capacity (kVA) Note 1)	0.6	1.3	1.8	3.0	4.2	1.8	3.1	4.2	7.2	11	13	21	25
Rating	Rated output current (A) Note 2)	1.5 (1.5)	3.3 (3.3)	4.8 (4.4)	7.8 (7.5)	11.0 (10.0)	2.3 (2.1)	4.1 (3.7)	5.5 (5.0)	9.5 (8.6)	14.3 (13.0)	17.0 (17.0)	27.7 (25.0)	33 (30)
	Rated output voltage Note 3)	3-phase 200V to 240V						<u>'</u>	3	-phase 38	OV to 500\	/		
	Overload current rating	60 se	conds at 15	50%, 0.5 s	econds at	200%	60 seconds at 150%, 0.5 seconds at 200%							
Power supply	Voltage-frequency	3	-phase 200	V to 240V	/ – 50/60H	Ηz	3-phase 380V to 500V - 50/60Hz							
Po Sup	Allowable fluctuation	Voltag	e +10%, -	15% Note 4), frequenc	y ±5%		٧	oltage +10	0%, -15%	Note 4), freq	uency ±5%	б	
Prote	ective method		IP20 Enclo	sed type (JEM1030)		IP20 Enclosed type (JEM1030)							
Cool	Cooling method			Forced air-	cooled		Forced air-cooled							
Colo	r	Munsel 5Y-8/0.5					Munsel 5Y-8/0.5							
Built-	in filter		High-at	tenuation E	MI filter				Hi	gh-attenuat	ion EMI filt	er		

Note) 3. Maximum output voltage is the same as the input voltage. 4. ±10% when the inverter is used continuously (load of 100%).

■Outline drawing



Note) 1. Capacity is calculated at 220V for the 200V models and at 440V for the 400V models.

2. Indicates rated output current setting when the PWM carrier frequency (parameter F300) is 4kHz or less.

When exceeding 4kHz, the rated output current setting is indicated in the parenthesis. When the input power voltage of the 400V class model exceeds 480V, it is necessary to further reduce the setting. The default setting of the PWM carrier frequency is 12kHz.

■Standard Specifications

	Item	Specification Specification
	Control system	Sinusoidal PWM control
Suc	Rated output voltage	Adjustable within a range of 100 to 120% of the corrected supply voltage (200/400V) (Unadjustable to any voltage higher than the input voltage).
ij	Output frequency range	0.5 to 400Hz, default setting: 0.5 to 80Hz, maximum frequency: 30 to 400Hz.
₫	Minimum setting steps of frequency	0.1Hz: operation panel setting, 0.2Hz: analog input (when the max. frequency is 100Hz).
Principal control functions	Frequency accuracy	Digital setting: within ±0.01% of the max. frequency (-10 to +50°C). Analog setting: within ±0.5% of the max. frequency (25°C±10°C).
ipal	Voltage/frequency characteristics	V/f constant, variable torque, vector control, automatic torque boost, Base frequency and torque boost amount adjustable.
Ë	Overload current rating	150% for 60 seconds.
_	Frequency setting signal	Front potentiometer and external potentiometer (rated impedance of connectable potentiometer: 1 to $10k\Omega$), 0 to $10Vdc$ (input impedance: $VIA=30.55\ k\Omega$, $VB=30\ k\Omega$), 4 to $20mAdc$ (input impedance: 400Ω), The characteristic can be set arbitrarily by two-point setting.
	Start-up frequency/frequency jump	Adjustable within a range of 0 to 10Hz / Up to 3 frequencies can be adjusted together with their widths.
	PWM carrier frequency (Note 1)	Adjustable within a range of 2.0 to 16.5Hz (default: 12kHz).
	Acceleration/deceleration time	0.1 to 3600 seconds, switchable between acceleration/deceleration time 1 and 2, selectable between S-pattern acceleration/deceleration 1 and 2.
Suc	Retry operation	Restart after a check of the main circuit elements in case the protective function is activated: 10 times (Max.) (adjustable with a parameter).
ä	Dynamic braking	With a built-in dynamic braking circuit, external braking resistor available (optional).
ij	DC braking	Braking start-up frequency: 0 to maximum frequency, braking rate: 0 to 100%, braking time: 0 to 20 seconds.
ion spe	Input terminal functions (selectable)	Forward/reverse run input signal, jog run input signal, standby signal, preset-speed operation input signal, reset input signal, etc. / Switching between sink/source.
Operation specifications	Output terminal functions (selectable)	Frequency lower limit output signal, frequency upper limit output signal, low-speed detection output signal, specified speed attainment output signal, etc. Open collector, RY output.
	Failure detection signal	1c-contact output: 250Vac/2A, cosø = 0.1, 250Vac/1A, cosø = 0.4, 3Vdc/1A.
	Output for frequency meter/output for ammeter	Analog output: (1mAdc full-scale DC ammeter or 7.5Vdc full-scale DC ammeter / Rectifier-type AC voltmeter, 225% current Max. 1mAdc, 7.5Vdc full-scale), 4 to 20mA/0 to 20mA output.
Protective function	Protective function	Stall prevention, current limitation, over-current, output short circuit, over-voltage, over-voltage limitation, undervoltage, ground fault, power supply phase failure, output phase failure overload protection by electronic thermal function, armature over-load at start-up (5.5kW or larger), load-side over-torque at start, pre-alarm, overheat.
tective	Protection against momentary power failure	Auto-restart/non-stop control after momentary power failure.
<u> </u>	Electronic thermal characteristic	Switching between standard motor/constant-torque VF motor, overload trip, overload stall selection.
Display function	4-digit 7-segments LED	Frequency: inverter output frequency. Alarm: stall alarm "C", overvoltage alarm "P", overload alarm "L", overheat alarm "H". Status: inverter status (frequency, cause of activation of protective function, input/output voltage, output current, etc.) and parameter settings. Free-unit display: arbitrary unit (e.g. rotating speed) corresponding to output frequency.
Disp	Indicator	Lamps indicating the inverter status by lighting, such as RUN lamp, MON lamp, PRG lamp, VEC lamp, ECN lamp, frequency setting potentiometer lamp, UP/DOWN key lamp and RUN key lamp. The charge lamp indicates that the main circuit capacitors are electrically charged.
Ė	Use environments	Indoor, altitude: 1000M (Max.), not exposed to direct sunlight, corrosive gas, explosive gas or vibration (less than 5.9m/s²) (10 to 55Hz).
ments	Ambient temperature	-10 to +60°C Note)1.2.3
<u>=</u>	Relative humidity	20 to 93% (free from condensation and vapor).

Note) 1. Above 40 : Remove the protective seal from the top of VF-S9.

2. Above 50 : Remove the protective seal from the top of VF-S9, and derate the rated output current by 3% for every 3. Side-by-side installation


• Model of 3.7kW or less: from -10 to 40 (Remove the protective seal from the top of VF-S9.)

• Model of 5.5kW or more: from -10 to 50

■External dimensions/weights

	Applicable motor		Dimensions (mm)								Approx. weight
Input voltage	(kW)	Туре	w	Н	D	W1	H1	H2	D2	Drawing	(kg)
	0.2	VFS9S-2002PL									1.9
	0.4	VFS9S-2004PL	105	130	140	93	118				1.9
1-phase 200V	0.75	VFS9S-2007PL						14	8.5	Α	1.9
·	1.5	VFS9S-2015PL	130	150	150	118	138	1			2.9
	2.2	VFS9S-2022PL	140	195	163	126	182]			4.5
	0.2	VFS9-2002PM					118	- 14			1.8
	0.4	VFS9-2004PM	105	130	130	93				A	1.8
	0.75	VFS9-2007PM	105		130	93					1.8
	1.5	VFS9-2015PM		150			138	'4			2.0
3-phase 200V	2.2	VFS9-2022PM	140	195	147	126	182		8.5		4.0
3-phase 200v	3.7	VFS9-2037PM	140	195	147	126	102				4.0
	5.5	VFS9-2055PL	200	270	170	180	255	12		В	9.2
	7.5	VFS9-2075PL		270		180				ь	9.2
	11	VFS9-2110PM	245	330	195	225	315	12		С	15.8
	15	VFS9-2150PM	245	330	195	225	315				15.8
	0.75	VFS9-4007PL	130	150	150	118	138				2.9
	1.5	VFS9-4015PL	130	150	150	118	138	14		A	2.9
	2.2	VFS9-4022PL	140	195	163	126	182] 14		_ ^	4.5
	3.7	VFS9-4037PL	140	195	103	126	182		8.5		4.5
3-phase 400V	5.5	VFS9-4055PL	000	070	170	100	055		0.5	В	9.2
	7.5	VFS9-4075PL	200	270	170	180	255			В	9.2
	11 VFSQ-4110PI	245	330	195	225	315	12		_	15.8	
	15	VFS9-4150PL	245	330	195	225	315			С	15.8

Function Description



What are parameters?

Each "setting item" that determines the control (operation) of an inverter is called a parameter. For example, the connection meter selection parameter (title FTSL) is adjusted to set the connection meter, the acceleration time parameter (title ACC) is adjusted to change the acceleration time, and the maximum frequency parameter (title FH) is adjusted to modify the maximum frequency. For the function you want to use, check the necessary parameter(s).

Basic parameters

• Four automatic functions

Title	Function	Unit	Adjustment range	Default setting	мемо
RU I	Automatic acceleration/ deceleration	-	0: Disabled (manual) 1: Optimum rate 2: Minimum rate	0	
AUS	Automatic torque boost		0: Disabled 1: Sensorless Vector control + auto-tuning	0	
RU3	Automatic environment setting		0: Disabled 1: Automatic setting	0	
RUY	Automatic function seting		0: Disabled 1: Coast stop 2: 3-wire operation 3: External input UP/ DOWN setting 4: 4-20mA current input operation	0	

- Note) 1. In case of the model of Type-form "-WN" and "-AN", default setting of parameter \$\mathcal{UL}\$, \$\mu L\$, \$\mu F \cdot 20^4\$, and \$\mu Z \cdot 13^4\$ are 60 (Hz).

 In case of "-WP", these parameter are 50 (Hz).

 2. The setting varies with the inverter capacity.

 3. Display units are changed by the setting of parameter \$\mu 70^4\$ t(unit selection).

 4. If 3 or 4 is set for parameter \$\mu 200^4\$ (frequency priority selection), the parameter function at the lower stage is active for \$\mu Z \cdot 10^4\$ for \$\mu Z \cdot 13^4\$.

Setup parameters

ullet When the standard setting ($m{E} \mbox{$\subseteq P=3$}$) is entered, the following parameter is displayed. Be sure to make that setting.

Title	Function	Unit	Adjustment range	Default setting	МЕМО
_	Applicable motor base frequency	Hz	60 50	*1	

Note) Make settings suitable for the applicable motor base frequency (reference frequency at rated torque of motor).

Other basic parameters

Title	Function	Unit	Adjustment range	Default setting	MEMO
CUOA	Command mode selection	-	0: Terminal board 1: Operation panel	1	
FNOd	Frequency setting mode selection	-	0: Terminal board 1: Operation panel 3: Internal potentiometer	2	
FNSL	Meter selection	-	0: Output frequency 1: Output current 2: Set frequency 3: For adjustment (current fixed at 100%) 4: Inverter load factor 5: Output power	0	
FΠ	Meter adjustment	-	_	-	
EYP	Standard setting mode selection	-	0~2: — 3: Default setting 4: Trip clear 5: Cumulative operation time clear 6: Initialization of type information	0	
Fr	Forward/reverse run selection (Operation panel)	-	0: Forward run 1: Reverse run	0	
RCC	Acceleration time 1	S	0.1 - 3600	10.0	
∂EC_	Deceleration time 1	S	0.1 - 3600	10.0	
FH	Maximum frequency	Hz	30.0 - 400	80.0	
UL	Upper limit frequency	Hz	0.5 - FH	*1	
LL	Lower limit frequency	Hz	0.5 - UL	0.0	
uL	Base frequency 1	Hz	25 - 400	*1	
PĿ	V/F control mode selection	-	0: V/F constant 1: Variable torque 2: Automatic torque boost 3: Sensorless vector control 4: Automaticv energy-saving	0	
ub	Torque boost	%/(V)	0.0 - 30.0 *3	*2	
EHr	Motor electronic- thermal protection level 1	%/(A)	10 - 100 *3	100	
OLN .	Electronic-thermal protection characteristic selection	-	Setting Type Overfload profection OL stall profection OL stall profection OL stall profection OL stall profession OL	0	
5r 1 to 5r 7	Preset-speed operation frequencies 1 to 7	Hz	LL - UL	0.0	
F	Extended parameter	-	_	-	
Gr. U	Automatic edit function	-	_	-	

How to read the monitor display?

Monitor display

The LEDs on the operation panel display the following symbols to indicate operations and parameters.

LED (number)

0	1	2	3	4	5	6	7	8	9	_
۵	1	2	3	4	5	5	٣	8	9	-

LED (alphabet)

Aa	Bb	Сс	Dd	Ee	Ff	Gg	Hh	Ti	Jj	Kk	LI	Mm
A	ь	E	đ	E	F	5	н	1			L	п
Nn	Оо	Pp	Qq	Rr	Ss	Tt	Uu	Vv	Ww	Хх	Yy	Zz
~	0	P		,-	5	E	U	u			7	

Extended parameters

Input/output parameters

F 100 F 10 1 F 102 F 103	Function Low-speed signal output frequency Speed reach setting frequency	Unit Hz	Adjustment range	Default setting	MEMO
F 10 1		Hэ			
F 102	Speed reach setting frequency	112	0.0 - FH	0.0	
		Hz	0.0 - FH	0.0	
F 103	Speed reach setting frequency	Hz	0.0 - FH	2.5	
	ST signal selection	-	0: Stand by on when ST is on 1: Stand by always on 2: Interlocked with F/R 3: Stand by on when ST is off	1	
F 104	RST signal selection	-	0: Default 1: Activated by turning RST off	0	
F 1 10	Always-active function selection	-	0 - 51	0	
F111	Input terminal selection 1 (F)	-	0 - 51 (F)	2	
F 1 12	Input terminal selection 2 (R)	-	0 - 51 (R)	3	
F 1 13	Input terminal selection 3 (RST)	-	0 - 51 (RST)	10	
F 1 14	Input terminal selection 4 (S1)	-	0 - 51 (SS1)	6	
F 1 15	Input terminal selection 5 (S2)	-	0 - 51 (SS2)	7	
F 1 15	Input terminal selection 6 (S3)	-	0 - 51 (SS3)	8	
F 130	Output terminal selection 1 (RY-RC)	-	0 - 29 (LOW)	4	
F 13 1	Output terminal selection 2 (OUT)	-	0 - 29 (RCH)	6	
F 132	Output terminal selection 3 (FL)	-	0 - 29 (FL)	10	
F 170	Base frequency 2	Hz	25 - 400	*1	
F 172	Torque boost 2	% (V)	0.0 - 30.0 *3	*2	
F 173	Motor electronic-thermal protection level 2	% (A)	0.0 - 30.0 *3	100	
F200	Frequency priority selection	_	VIA/II, VIB, 1: VIB, VIA/II External switching (FCHG enabled) External contact UP/DOWN *4 External contact UP/DOWN *4 (Setting retained even if the power is turned off) VIAI/II+VB	0	
F20 1	VIA/II input point 1 setting	%	0 - 100	0	
F202	VIA/II input point 1 frequency	%	0.0 - 400.0	0.0	
F203	VIA/II input point 2 setting	%	0 - 100	100	
F204	VIA/II input point 2 frequency	%	0.0 - 400.0	*1	
F2 10	VIB input point 1 setting	%	0 - 100	0	
5344	Frequency UP response time *4	(0.1s) Hz	0 - 100 0.0 - 400.0	0	
F211	VIB input point 1 frequency Frequency UP step width *4	П	0.0 - 400.0	0	
	VIB input point 2 setting	%	0.0 - 400.0	100	
F2 12	Frequency DOWN response time *4	(0.1s)	0.0 - 400.0	100	
F2 13	VIB input point 2 frequency	Hz	0 - 400	*1	
re 13	Frequency DOWN step width *4	112	0.0 - 400.0	60.0	
F240	Starting frequency setting	Hz	0.5 - 10.0	0.5	
F240	Operation starting frequency	Hz	0.0 - FH	0.0	
F242	Operation starting frequency	Hz	0.0 - F H	0.0	
	hysterisis				
F250	DC braking starting frequency	Hz	0.0 - 20.0	0.0	
F25 1	DC braking current	% (A)	0 - 100	30	
F252	DC braking time	S	0.0 - 20.0	1.0	
F260	Jog run stopping pattern	Hz	0.0 - 20.0	0.0	
F26 1	Jog run stopping pattern	_	0: Slowdown stop, 1: Coast stop 2: DC braking	0	
F270	Jumping frequency 1	Hz	LL- UL	0.0	
F271	Jumping width 1	Hz	0.0 - 30.0	0.0	
FETE	Jumping frequency 2	Hz	LL- UL	0.0	
F273	Jumping width 2	Hz	0.0 - 30.0	0.0	
F274	Jumping frequency 3	Hz	LL- UL	0.0	
F275	Jumping width 3	Hz	0.0 - 30.0	0.0	
F280 to F294	Preset-speed operation frequencies 1 to 15	Hz	LL- UL	0.0	

• Operation mode parameters

	ition mode parametere	l		Default	
Title	Function	Unit	Adjustment range	setting	MEMO
F300	PWM carrier frequency	kHz	2.0 - 16.5	12.0	
F30 1	Auto-restart control selection	-	O: Disabled I: At auto-restart after momentary stop S: When turning ST-CC on or off G: At auto-restart or when turning ST-CC on or off 4: Motion of DC braking at start-up (at auto-restart after momentary stop). Motion of DC braking at start-up (when turning ST-CC on or ff) G: Motion of DC braking at start-up (at auto-restart or when turning ST-CC on or or off) ST-CC on or off)	0	
F302	Regenerative power ride-through control	-	0: Disabled 1: Enabled	0	
F303	Retry selection (number of times)	Times	0 - 10	0	
F304	Dynamic braking selection	-	Dynamic braking disabled Dynamic braking enabled, overload protection disabled Dynamic braking enabled, overload protection enabled	0	
F305	Overvoltage stall operation	-	0: Enabled, 1: Disabled	0	
F306	Output voltage adjustment (Base frequency voltage)	V	0 - 250 / 0 - 500	200/400	
F307	Supply voltage compensation	-	O: Supply voltage uncorrected, output voltagelimited I: Suply voltage corrected, output voltage initiated I: Supply voltage corrected (off during deceleration), output voltage limited I: Supply voltage uncorrected, output voltage unlimited I: Supply voltage corrected, output voltage limited S: Supply voltage corrected (off during deceleration), output voltage unlimited unlimited I: Supply voltage vorrected (off during deceleration), output voltage unlimited III voltage Vol	1	
F308	Braking resistor operation rate	%ED	1 - 100	3	
F3 12	Random mode	-	0: Disabled, 1: Enabled	0	
F360	PI control	-	0: Disabled, 1: Enabled	0	
F362	Proportional gain	-	0.01 - 100.0	0.30	
F363	Integral gain	-	0.01 - 100.0	0.20	

Torque boost parameters

Title	Function	Unit	Adjustment range	Default setting	MEMO
F400	Auto-tuning	-	0: Auto-tuning disabled (use of internal parameters) 1: Application of individual settings of FYO 1 to FYOS 2: Auto-tuning enabled (returns to 1 after auto-tuning)	0	
F40 1	Slip frequency	Hz	0.0 - 10.0	*2	
F402	Motor primary constant	-	0 - 255	*2	
F403	Motor secondary constant	-	0 - 255	*2	
FYDY	Motor excitation constant	-	0 - 255	*2	
F405	Magnification of load inertial moment	Times	0 - 200	0	
F408	Rated capacity ratio of motor to inverter	-	Same capacity as interver One-size smaller than inverter	0	

Acceleration/deceleration time parameters

Tit	tle	Function	Unit	Adjustment range	Default setting	МЕМО
FS	00	Acceleration time 2	S	0.1 - 3600	10.0	
FS	01	Deceleration time 2	S	0.1 - 3600	10.0	
FS	02	Acceleration/deceleration 1 pattern	-	0: Linear 1: S-pattern 1	0	
FS	03	Acceleration/deceleration 2 pattern		2: S-pattern 2	0	
FS		Acceleration/deceleration pattern selection (1 or 2)	-	0: Acceleration/deceleration 1 1: Acceleration/deceleration 2	0	
FS	05	Acceleration/deceleration 1 and 2 switching frequency	Hz	0- UL	0.0	

Protection parameters

Title	Function	Unit	Adjustment range	Default setting	МЕМО
F600	Motor electronic-thermal protection level 1	% (A)	10 - 100 *3	100	
F60 1	Stall prevention level	% (A)	10 - 199, 200 (disabled) *3	150	
F602	Inverter trip retention selection	-	0: Not retained, 1: Retained	0	
F603	External input trip stop mode selection	-	0: Coast stop, 1: Slowdown stop 2: Emergency DC braking	0	
F604	Emergency DC braking time	S	0.0 - 20.0	1.0	
F60S	Output phase failure detection selection	-	0: Disabled, 1: Enabled	0	
F608	Input phase failure detection mode selection	-	0: Disabled, 1: Enabled	1	
F6 10	Small current trip selection	-	0: Disabled, 1: Enabled	0	
F6 11	Small current (trip/alarm) detectin current	%	0 - 100	0	
F6 12	Small current (trip/alarm) detectin time	S	0 - 255	0	
F6 15	Over-torque trip selection	-	0: Disabled, 1: Enabled	0	
F6 16	Over-torque (trip/alarm) level	%	0 - 200	150	
F6 18	Over-torque detection time	S	0 - 10	0.5	
F6 19	Over-torque (trip/alarm) level hysterisis	%	0 - 100	10	
F627	Undervoltage trip selection	-	Disabled Enabled (at 70% or les) Disabled (at 50% or less, optional soon to be relreased)	0	
F692	Meter bias	%	0: - 50	0	


Operation panel parameters

Title	Function	Unit	Adjustment range	Default setting	МЕМО
F 100	Prohibition of change of parameter settings	-	0: Permitted (CND and FND and cannot be changed during operation.) 1: Prohibited 2: Permitted (CND and FND also cannot be changed during operation.)	0	
FIOI	Unit selection	-	0: No change 1: % → A (ampere)/V (volt) 2: Permitted (「 no d and Fno d cannot be changed during operation.) 3: % → A (ampere)/V (volt) Free unit selection enabled (F 100 2)	0	
F702	Free unit selection	-	0.01 - 200.0	1.00	
F710	Standard monitor display selection	-	O: Operation frequency (Hz/free unit) 1: Output current (%A) 2: Frequency command (Hz/free unit) 3: Inverter rate current (A) 4: Inverter over load factor (%) 5: Output power (%)	0	

■ Communication parameters

Title	Function	Unit	Adjustment range	Default setting	МЕМО
F800	Communication band speed	-	0: 1200bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200bps	3	
F80 1	Parity	-	0: NON 1: EVEN 2: ODD	1	
F802	Inverter number	-	0 - 63	0	
F803	Communication error trip time	S	0 (Disabled), 1 - 100	0	

Connection Diagram and Selection of Wiring Devices



Selection of wiring devices

	Capacity		Non-fus breaker		Magnetic (M		Overload (Th-R			eakage aker	Wire size (mm²)					
Voltage class	applicable motor (kW)	Interver model	Rated current (A)	Type Note 1)	Rated current (A)	Type Note 1)	Adjusted current (A) (For reference)	Type Note 1)	Rated current (A)	Type Note 1)	Main circuit (mm²) Note 4)	DC reactor (optional) (mm²)	Braking resistor/ Braking unit (optional) (mm²)	Grounding cable (mm²) Note 6)		
	0.2	VFS9S-2002PL	10	SS30	11	C11J	1.3	T13J	10	LES50	2.0	1.25	1.25	3.5		
1-phase	0.4	VFS9S-2004PL	15	SS30	11	C11J	2.3	T13J	15	LES50	2.0	1.25	1.25	3.5		
200V class	0.75	VFS9S-2007PL	20	SS30	11	C11J	3.6	T13J	20	LES50	2.0	2.0	1.25	3.5		
	1.5	VFS9S-2015PL	30	SS30	18	C20J	6.8	T13J	30	LES50	3.5	2.0	1.25	3.5		
	2.2	VFS9S-2022PL	40	ES50	35	C35J	9.3	T13J	40	LES50	5.5	2.0	2.0	5.5		
	0.2	VFS9-2002PM	5	SS30	11	C11J	1.3	T13J	5	LES50	2.0	1.25	1.25	3.5		
	0.4	VFS9-2004PM	5	SS30	11	C11J	2.3	T13J	5	LES50	2.0	1.25	1.25	3.5		
	0.75	VFS9-2007PM	10	SS30	11	C11J	3.6	T13J	10	LES50	2.0	2.0	1.25	3.5		
	1.5	VFS9-2015PM	15	SS30	11	C11J	6.8	T13J	15	LES50	2.0	2.0	1.25	3.5		
3-phase 200V class	2.2	VFS9-2022PM	20	SS30	13	C13J	9.3	T13J	20	LES50	2.0	2.0	2.0	3.5		
ZUUV GIASS	3.7	VFS9-2037PM	30	SS30	26	C25J	15	T20J	30	LES50	3.5	5.5	5.5	3.5		
	5.5	VFS9-2055PL	50	ES50	35	C35J	22	T35J	50	LES50	8.0	5.5	5.5	8.0		
	7.5	VFS9-2075PL	60	EH100B	50	C50J	28	T35J	60	LES60	14	14	5.5	14		
	11	VFS9-2110PM	100	EH100B	65	C65J	44	T65J	100	LEH100B	14	14	5.5	14		
	15	VFS9-2150PM	125	EH225B	80	C80A	57	T65J	125	LEH225B	22	22	5.5	22		
	0.75	VFS9-4007PL	5	SS30	9	C11J	1.6	T13J	5	LES50	2.0	1.25	1.25	3.5		
	1.5	VFS9-4015PL	10	SS30	9	C11J	3.6	T13J	10	LES50	2.0	1.25	1.25	3.5		
	2.2	VFS9-4022PL	15	SS30	9	C11J	5.0	T13J	15	LES50	2.0	2.0	1.25	3.5		
3-phase	3.7	VFS9-4037PL	20	SS30	13	C13J	6.8	T13J	20	LES50	2.0	2.0	1.25	3.5		
400V class	5.5	VFS9-4055PL	30	SS30	17	C20J	11	T13J	30	LES50	3.5	2.0	2.0	3.5		
	7.5	VFS9-4075PL	30	SS30	25	C25J	15	T20J	30	LES50	3.5	3.5	2.0	3.5		
	11	VFS9-4110PL	50	ES50	33	C35J	22	T35J	50	LES50	5.5	5.5	3.5	5.5		
	15	VFS9-4150PL	60	EH100B	48	C50J	28	T35J	60	LEH100B	8.0	8.0	3.5	8.0		

- Note) 1. Produced by Schneider Toshiba electric corporation.
 2. Be sure to attach surge killer to the exciting coil of the relay and the magnetic contactor.

 - Selection of surge killers for Toshiba magnetic contactors
 200V class: Surge absorbing units are optionally available for Toshiba C11J to C65J, or Model SS-2 for C50J and C65J
 - 400V class: For the operation and control circuit, regulate the voltage at 200V or less with a step-down
- Note) 3. When using the auxiliary contacts 2a of the magnetic contactor MC for the control circuit, connect the contacts 2a in parallel to increase reliability.
 - 4. Size of the wires conected to the input terminals R, S and T and the output terminals U, V and W when the length of each wire does not exceed 30m.

 5. For the control circuit, use shielded wires 0.75 mm² or more in diameter.

 - 6. For grounding, use a cable with a size equal to or larger than the above.

Terminal Functions

Main circuit teminal functions


Terminals symbol	Terminal function
	Grounding terminal for connecting inverter case. 2 grounding terminals.
R/L1, S/L2, T/L3	200V class: 1-phase 200 to 240V - 50/60Hz 3-phase 200 to 230V - 50/60Hz 400V class: 3-phase 380 to 500V - 50/60Hz * 1-phase series have R/L1 and S/L2 terminal.
U/T1, V/T2, W/T3	Connect to a (3-phase induction) motor.
PA, PB	Connect to braking resistors. Change parameters F304 F305 and F308 if necessary.
PC	This is a negative potential terminal in the internal DC main circuit. DC common power can be input across the PA terminals (positive potential).
PO, PA	Terminals for connecting a DC reactor (DCL: optional external device). Shorted when shipped from the factory. Before installing DCL, remove the short bar.

Control circuit terminal functions

Terminal symbol		Function	Electrical specifications	Wire size		
F	ple	Shorting across F-CC causes forward rotation; open causes slowdown and stop.				
R	ramma	Shorting across R-CC causes reverce rotation; open causes slowdown and stop.	Dry contact input 24Vdc - 5mA or less			
RST	Multifunction programmable contact input	Shorting across RST-CC causes a held reset when the inverter protector function is operating. Note that when the inverter is operating normally, it will not operate even if there is a short across RST-CC.	* Sink/source switchable			
S1	lun c	Shorting across S1-CC causes preset speed operation.	_			
S2	l ii	Shorting across S2-CC causes preset speed operation.				
S3	_	Shorting across S3-CC causes preset speed operation.				
CC		rol circuit's equipotential terminal (sink logic). mmon terminals for input/output.				
PP	Powe	er output for analog input setting.	10Vdc (permissible load current: 10mAdc)	Solid wire : 0.3 to 1.5 (mm²)		
II*	Stand	function programmable analog input. dard default setting: 4 (0) to 20mAdc input and 0-50Hz (50Hz setting) 60Hz (60Hz setting) frequency.	4 to 20mA (internal impedance: 400Ω)	Stranded wire : 0.3 to 1.25 (mm²) (AWG22 to 16) Sheath strip length : 5 (mm)		
VIA*		function programmable analog input. dard default setting: 0-10Vdc input and 0-80Hz frequency.	10Vdc (internal impedance: 30kΩ)			
VIB	Stan	function programmable analog input. dard default setting: 0-10Vdc input and 0-50Hz (50Hz setting) or 0- z (60Hz setting) frequency.	10Vdc (internal impedance: 30kΩ)			
FM	Stand	function programmable analog output. dard default setting: output current. Connect a 1mAdc full-scale leter or 7.5Vdc (10Vdc)-1mA full-scale voltmeter. Can change to 0- A (4-20mA) by jumper switching.	1mA full-scale DC ammeter or 7.5Vdc 1mA full-scale DC voltmeter *Switchable for jumpper 0 to 20mA (4 to 20mA) DC ammeter			
P24	24V	dc power output/common at source logic.	24Vdc - 100mA			
OUT		function programmable open collector output. Standard default settings ct and output speed reach signal output frequencies.	Open collector output: 24Vdc - 50mA			
	ucici	or and output speed reach signal output hequelicies.	*Sink-source selectable			
RC RY	Cont (cose	function programmable relay contact output. act ratings: 250Vac - 2A (cosø = 1), 30Vdc - 1A, 250Vac - 1A a = 0.4). dard default settings detect and output low-speed signal output frequencies.	250Vac - 2A: at resistance load 30Vdc - 1A, 250Vac - 1A (cosø = 0.4)	Solid wire: 0.3 to 1.5 (mm²) Stranded wire: 0.3 to 1.5 (mm²)		
FLA FLB FLC	Cont (cose Dete FLC	function programmable relay contact output. act ratings: 250Vac-2A (cosø = 1), 30Vdc-1A, 250Vac-1A by = 0.4). cts the opertion of the inverter's protection function. Contact across FLA- is closed and FLB-FLC is opened during protection function operation.	250Vac - 2A: at resistance load 30Vdc - 1A, 250Vac - 1A (cosø = 0.4)	Stranded wire: 0.3 to 1.5 (mm²) (AWG22 to 16) Sheath strip length: 6 (mm)		

^{*} The VIA terminal and I I terminal cannot be used at the same time.

Inverter Q & A




How can I use the inverter immediately?

Just connect the power supply and the motor, and you can use the VF-S9 series inverter immediately.

You can use the RUN and STOP keys and the frequency setting potentiometer to easily operate the inverter. You can also make adjustments easily using the automatic setting functions.

- · Automatic acceleration/deceleration: Automatically adjusts the acceleration or deceleration time according to the load.
- Automatic torque increase: Automatically improves the motor torque according to the load.
- · Automatic environment setting: Automatically makes all the settings related to the inverter environment protection at one time.
- Automatic function setting: Selects the inverter operation method.



Q 2 What can I do if I forget what I have programmed?

You can use the change setting retrieval function. You can also use the following operation to restore all the parameters to the default values immediately.

1) Change setting retrieval (Ert): Automatically retrieves and displays only the parameters differing from the default setting. You can confirm the changed parameters.



2) Standard setting mode selection (**LYP**):

Restores all the parameters to the default values.







Pressing the MON (monitor) key, and pressing the DOWN key









Parameter Setting **E YP** (standard setting mode selection) 3 (default value)

Note) When the defaurt setting is entered, the system enters the setup parameter mode

How can I change the frequency by contact input in combination with a PC (programmable controller)?

Incorporating a standard 15-step speed function, the VF-S9 series allows you to change the frequency by setting parameters and using contact input.


Multi-step contact input signal samples

○: ON —: OFF (Speed command other than a preset-speed becomes effective when all contacts are OFF.)

	٠,	Terminal	Preset-speed														
s		Terminar	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
S		S1-CC	0	_	0	_	0	_	0	_	0	_	0	_	0	_	0
S		S2-CC	-	0	0	_	_	0	0	_	_	0	0	_	-	0	0
RS		S3-CC	_	_	_	0	0	0	0	_	_	_	_	0	0	0	0
L	· ĭ /	RST-CC	_	_	_	_	_	_	_	0	0	0	0	0	0	0	0

ou can abango the frequency using contact input


Tou can change the frequency using contact input.	
Parameter	Setting
Sr 1(F280)(Preset-speed operation frequencies1)	Lower limit frequency-Upper limit frequency :
5r7 (F286)(Preset-speed operation frequencies7)	Lower limit frequency-Upper limit frequency
F294 (Preset-speed operation frequencies 15) F 1 14 (Input terninal Selection 4) F 1 15 (Input terninal Selection 6) F 1 15 (Input terninal Selection 6) F 1 13 (Input terninal Selection 3)	Lower limit frequency-Upper limit frequency (Preset-speed command 1) (Preset-speed command 2) (Preset-speed command 3) (Preset-speed command 4)



Q4 What is the input/output programmable terminal block?

f The VF-S9 series allows you to set the terminal functions as you wish from a broad menu selection.

Parameter	Setting
F 111 Input terminal selection 1(F)	∠ (Forward run)
F 1 12 Input terminal selection 2(R)	∄ (Reverse run)
F 113 Input terminal selection 3(RST)	I ☐ (Reset)
F 1 14 Input terminal selection 4(S1)	万 (Preset-speed 1)
F 1 15 Input terminal selection 5(S2)	7 (Preset-speed 2)
F 1 15 Input terminal selection 6(S3)	₽ (Preset-speed 3)
F 13D Output terminal selection 1 (RY-RC)	
F 13 1 Output terminal selection 2(OUT)	(Designated frequency reach)
F 132 Output terminal selection 3(FL)	∤ (Failure FL)



■ Table of input terminal functions

Function No.	Code	Function
0	_	No function is assigned
1	ST	Standby terminal
2	F	Forward-run command
3	R	Reverse-run command
4	JOG	Jog run command
5	AD2	Acceleration/deceleration 2 pattern selection
6	SS1	Preset-speed command 1
7	SS2	Preset-speed command 2
8	SS3	Preset-speed command 3
9	SS4	Preset-speed command 4
10	RST	Reset command
11	EXT	Trip stop command from external input device
12	PNL/TB	Operation panel/terminal board switching
13	DB	DC braking command
14	PI	Prohibition of PI control
15	PWENE	Permission of parameter editing
16	ST+RST	Combination of standby and reset commands
17	ST+PNL/TB	Combination of standby and operation panel/terminal board switching
18	F+JOG	Combination of forward run and jog run
19	R+JOG	Combination of reverse run and jog run
20	F+AD2	Combination of forward run and acceleration/deceleration 2
21	R+AD2	Combination of reverse run and acceleration/deceleration 2
22	F+SS1	Combination of forward run and preset-speed command 1
23	R+SS1	Combination of reverse run and preset-speed command 1
24	F+SS2	Combination of forward run and preset-speed command 2
25	R+SS2	Combination of reverse run and preset-speed command 2
26	F+SS3	Combination of forward run and preset-speed command 3
27	R+SS3	Combination of reverse run and preset-speed command 3
28	F+SS4	Combination of forward run and preset-speed command 4
29	R+SS4	Combination of reverse run and preset-speed command 4
30	F+SS1+AD2	Combination of forward run, preset-speed command 1 and acceleration/deceleration 2
31	R+SS1+AD2	Combination of reverse run, preset-speed command 1 and acceleration/deceleration 2
32	F+SS2+AD2	Combination of forward run, preset-speed command 2 and acceleration/deceleration 2
33	R+SS2+AD2	Combination of reverse run, preset-speed command 2 and acceleration/deceleration 2
34	F+SS3+AD2	Combination of forward run, preset-speed command 3 and acceleration/deceleration 2
35	R+SS3+AD2	Combination of reverse run, preset-speed command 3 and acceleration/deceleration 2
36	F+SS4+AD2	Combination of forward run, preset-speed command 4 and acceleration/deceleration 2
37	R+SS4+AD2	Combination of reverse run, preset-speed command 4 and acceleration/deceleration 2
38	FCHG	Frequency command forced switching
39	THR2	No. 2 thermal switching
40	MCHG	No. 2 motor switching
41	UP	Frequency UP signal input from external contacts
42	DOWN	Frequency DOWN signal input from external contacts

Function No.	Code	Function						
43	CLR	Frequency UP/DOWN clear signal input from external contacts						
44	CLR+RST	Combination of frequency UP/DOWN clear and reset by means of external contacts						
45	EXTN	Inversion of trip stop command from external device						
46	ОН	Thermal trip stop signal input from external device						
47	OHN	Inversion of thermal trip stop command from external device						
48	SC/LC	Remote/local control forced switching						
49	HD	Operation holding (stop of 3-wire operation)						
50	SDBF	Forward run after DC braking						
51	SDBR	Reverse run after DC braking						

■ Table of output terminal functions

Function No.	Code	Code Function						
0	LL	Frequency lower limit						
1	LLN	Inversion of frequency lower limit						
2	UL	Frequency upper limit						
3	ULN	Inversion of frequency upper limit						
4	LOW	Low-speed detection signal						
5	LOWN	Inversion of low-speed detection signal						
6	RCH	Designated frequency reach signal (completion of acceleration/deceleration)						
7	RCHN	Inversion of designated frequency reach signal (inversion of completion of acceleration/deceleration)						
8	RCHF	Set frequency reach signal						
9	RCHFN	Inversion of set frequency reach signal						
10	FL	Failure FL (trip output)						
11	FLN	Inversion of failure FL (inversion of trip output)						
12	ОТ	Over-torque detection						
13	OTN	Inversion of over-torque detection						
14	RUN	RUN/STOP						
15	RUNN	Inversion of RUN/STOP						
16	POL	OL pre-alarm						
17	POLN	Inversion of OL pre-alarm						
18	POHR	Braking resistor overload pre-alarm						
19	POHRN	Inversion of braking resistor overload pre-alarm						
20	POT	Over-torque detection pre-alarm						
21	POTN	Inversion of over-torque detection pre-alarm						
22	PAL	Pre-alarm						
23	PALN	Inversion of pre-alarm						
24	UC	Low-current detection						
25	UCN	Inversion of low-current detection						
26	HFL	Hard fault						
27	HFLN	Inversion of hard fault						
28	LFL	Soft fault						
29	LFLN	Inversion of soft fault						

Q5 How can I get a large torque?

A5 The VF-S9 series ensures a torque of 150% or more from low speeds by utilizing Toshiba's sensorless vector control.

Enable the sensorless vector control for a load that requires high starting or low speed torque.

To use sensorless vector control

- When automatic torque increase FUE = t is set, all the sensorless vector controls and motor constants are set at one time.
- 2) Set V/F control mode selection **PL=3** (sensorless vector control). Set the motor constant.
- For the same capacity as the inverter with the 4P Toshiba standard motor, it is not necessary to set the motor constants.
- (2) The motor constants can be automatically set using the auto-tuning function $F \lor DD = Z$ (Auto tuning).
- (3) The motor constants can be set individually.

FYD 1: Slip frequency

F 402: Motor primary constant F 403: Motor secondary constant F 404: Motor excitation constant

FYD5: Magnification of load inertial moment
FYD8: Rated capacity ratio of motor to inverter

12


Inverter Q & A

How do I start/stop a motor by external contacts, and control the frequency by a current signal of 4-20 mA (or a voltage signal of 0-10 Vdc.)

To allow start/stop of the motor by external contacts, and to control the frequency by a current (voltage) signal, you need to set the following parameters:

■ Parameters to be changed

	Parameter	Setting
CUOA	(Command mode selection)	O (Terminal board)
FNOd	(Frecuency setting mode selection)	O (Terminal board)



E□□□□ (Command mode selection) is a parameter to determine the source of the operation signal.

For performing run/stop through a terminal set to 0 (terminal board).

For performing run/stop with RUN/STOP key on the set to 1 (panel).

FDDd (Frequency setting mode selection) is a parameter to determine the place for providing frequency command.

For providing frequency by current (voltage) signal through a terminal

set to 0 (terminal board).

For setting with UP/DOWN key on the panel

To be set on 1 (operation panel).

For setting with potentiometer

To be set to 2 (internal potentiometer).

Note) Because they are connected to each other in the inverter, the VIA and II terminals cannot be used jointly. Use terminal VIB for joint use with terminal II.


Why do other devices malfunction due to noise?

Using PWM control, the VF-S9 series generates noise that may affect nearby instrumentation and electronic equipment.

Noise is classified by propagation route into: transmission noise, and radiation noise.

Take the following counter measures for noise which affects other equipment:

- Separate the signal cables from the power cables with sufficient distance.
- Install noise filters.
- *VF-S9 series have a built-in noise filter (primary of inverter).
- Use twisted-pair shielding cables for weak electric circuits and signal circuits, and be sure to ground one end of the shielding.
- Install the inverters separately from other equipment.
- · Cover the inverters and their cables with metal conduit tubes and metal control panels, and ground these
- EMC plate is attached for measures of radiation noise.







To users of our inverters

When wiring the inverter

(Wiring precautions)

Installing a no-fuse breaker [MCCB]

- Install a molded-case circuit breaker (MCCB) on the inverter's power supply input to protect the wiring.
- (2) Avoid turning the no-fuse breaker on and off frequently to turn on/off the motor.
- (3) To turn on/off the motor frequently, close/break the control terminals F (or R)-CC.

Installing a magnetic contactor [MC] [primary side]

- (1) To prevent an automatic restart after the power interruption or overload relay has tripped, or actuation of the protective circuit, install an electro-magnetic contact in the power supply.
- (2) Because the VF-S9 inverter has a built-in fault detection relay [FL], the primary end magnetic contactor (MC) can be configured to trip on activation of the inverter's protective functions by connecting the contact points of the FL to the operation circuit of the MC.
- (3) The inverter can be used without a magnetic contactor. In this case, use an MCCB (equipped with a voltage tripping device) for opening the primary circuit when the inverter protective circuit is activated.
- (4) Avoid turning the magnetic contactor on and off frequently to turn on/off the motor.
- (5) To turn of/off the motor frequently, close/break the control terminals F (or R)-CC.
- (6) Install a surge suppressor on the excitation coil of the magnetic contactor (MC)

Installing a magnetic contactor [MC] [secondary side]

- (1) As a rule, if a magnetic contactor is installed between the inverter and the motor, do not turn of ON/OFF while running. (If the secondary-side contactor is turned of ON/OFF while running, a large current may flow in the inverter, causing inverter damage and failure.)
- (2) A magnetic contactor may be installed to change the motor or change to the commercial power source when the inverter is stopped. Always use an interlock with the magnetic contactor in this situation so that the commercial power supply is not applied to the inverter's output terminals.

External signal

- Use a relay rated for low currents. Mount a surge suppressor on the excitation coil of the relay.
- (2) When wiring the control circuit, use shielded wires or twisted pair cables.
- (3) Because all of the control terminals except FLA, FLB and FLC are connected to electronic circuits, insulate these terminals to prevent them from coming into contact with the main circuit.

Installing an overload relay

- (1) The VF-S9 inverter has a built-in overload protection function by means of a thermal relay. However, in the following cases, the thermal relay operation level must be adjusted or an overload relay matching the motor's characteristics must be installed between the inverter and the motor.
 - (a) When using a motor having a rated current value different from that of the equivalent.
 - (b) When driving several motors simultaneously.
- (2) When you want to use a constant-torque Toshiba VF motor together with the VF-S9 inverter, change the inverter's electronic thermal protection characteristics to match those of the VF motor.
- (3) In order to adequately protect a motor used for low-speed operation, we recommend the use of a motor equipped with a embedded thermal relay.

When changing the motor speed

Application to standard motors

Vibration

When a motor is operated with an industrial inverter, it experiences more vibrations than when it is operated by the commercial power supply. The vibration can be reduced to a negligible level by securing the motor and machine to the base firmly. If the base is weak, however, the vibration may increase at a light load due to resonance with the mechanical system.

Reduction gear, belt, chain

Note that the lubrication capability of a reducer or a converter used as the interface of the motor and the load machine may affected at low speeds. When operating at a frequencies exceeding 60 Hz or higher, power transmission mechanisms such as reduction gear, belts and chains, may cause problems such as production of noise, a reduction in strength, or shortening of service life.


Frequency

Before setting the maximum frequency to 60 Hz or higher, confirm that this operating range is acceptable for the motor.

Application to special motors

Braking motor

When using a braking motor, if the braking circuit is directly connected to the inverters's output terminals, the brake cannot be released because of the lowered starting voltage. Therefore, when using a braking motor, connect the braking circuit to the inverter's power supply side, as shown in the figure below. Usually, braking motors produce larger noise in low speed ranges.



Gear motor

When using an industrial inverter to drive a gear motor, inquire of the motor manufacturer about its continuous operation range, since low-speed operation of a gear motor may cause insufficient lubrication.

Toshiba Gold Motor (High-efficiency power-saving motor)

Inverter-driven operation of Toshiba Gold Motors is the best solution for saving energy. This is because these motors have improved efficiency, power factor, and noise/vibration reduction characteristics when compared to standard motors.

Pole-changing motor

Pole-changing motors can be driven by the VF-S9 inverter. Before changing poles, however, be sure to let the motor come to a complete stop.

Hight-pole-count motors

Note that hight-pole count motors(8 or more poles), which may be used for fans,etc., have higher rated current than 4-pole moters.

The current ratings of multipole motors are relatively high. So, when selecting an inverter, you must pay special attention to its current rating so that the current rating of the motor is below that of the inverter.

Single-phase motor

Because single-phase motors are equipped with a centrifugal switch and capacitors for starting, they cannot be driven by an inverter. If only a single-phase, power system is available a 3-phase motor can be driven by using a single-phase input interter to convert it into a 3-phase 200V output. (A special inverter and a 3-phase motor are required.)

To users of our inverters

When studying how to use our inverters

Notes

Leakage current

The VF-S9 series of inverters uses high-speed switching deuices for PWM control. When a relatively long cable is used for power supply to an inverter, current may leak from the cable or the motor to the ground because of its capacitance, adversely affecting peripheral equipment. The intensity of such a leakage current depends on the PWM carrier frequency, the lengths of the input and output cables, etc., of the inverter. To prevent current leakage, it is recommended to take the following measures.

[Effects of leakage current]

Leakage current which increases when an inverter is used may pass through the following routes:

- Route (1) ... Leakage due to the capacitance between the ground and the noise filter
- Route (2) ... Leakage due to the capacitance between the ground and the inverter
- Route (3) ... Leakage due to the capacitance between ground and the cable connecting the inverter and the motor
- Route (4) ... Leakage due to the capacitance of the cable connecting the motor and an inverter in another power distribution line
- Route (5) ... Leakage through the grounding line common to motors
- Route (6) ... Leakage to another line because of the capacitance of the ground


Leakage current which passes through the above routes may cause the following trouble

Malfunction of a leakage circuit breaker in the same or another power distribution line

Malfunction of a ground-relay installed in the same or another power distribution line

Noise produced at the output of an electronic device in another power

Activation of an external thermal relay installed between the inverter and the motor, at a current below the rate current



[Measures against effects of leakage current]

The measures against the effects of leakage current are as follows:

- 1) Measures to prevent the malfunction of leakage circuit breakers
- (1) Decrease the PWM carrier frequency of the inverter. In the case of the VF-S9, the frequency can be decreased to 2.0kHz. (*)
- (2) Install leakage circuit breakers (ELCB) with a high-frequency protective function (e.g., Toshiba Mighty series of breakers) in both the same and the other power distribution lines. This makes it possible to operate the VF-S9 with its PWM carrier frequency set high.
- 2) Measures against malfunction of ground-fault relay:
- (1) Decrease the PWM carrier frequency of the inverter. In the case of the VF-S9, the frequency can be decreased to 2.0kHz. (*)
- (2) Install ground-fault relays with a high-frequency protective function (e.g., Toshiba CCR12 type of relays) in both the same and other lines. This makes it possible to operate the VF-S9 with its PWM carrier frequency set high.
- 3) Measures against noise produced by other electric and electronic
 - systems:
 (1) Separate the grounding line of the inverter from that of the affected electric and electronic systems.
 - (2) Decrease the PWM carrier frequency of the inverter. In the case of the VF-S9, the frequency can be decreased to 2.0kHz. (*)
- 4) Measures against malfunction of external thermal relays:
 - (1) Remove the external thermal relay and use the electronic thermal function of the inverter instead of it. (Unapplicable to cases where a single inverter is used to drive more than one motor. Refer to the instruction manual for measures to be taken when thermal relavs cannot be removed.)
 - (2) Decrease the PWM carrier frequency of the inverter. In the case of the VF-S9, the frequency can be decreased to 2.0kHz.

Note) If the carrier frequency reduce, the magnetic noise caused by the motor increase

- 5) Measures by means of wiring and grounding
 - (1) Use a grounding wire as large as possible.
 - (2) Separate the inverter's grounding wire from that of other systems or install the grounding wire of each system separately to the grounding point.
 - (3) Ground (shield) the main circuit wires with metallic conduits.
 - (*): The PWM carried frequency should not be decreased below 2.2kHz in the vector control mode.

Before begining operation, thoroughly check the wiring between the motor and the inverter for incorrect wiring or short circuits. Do not ground the neutral point of any star-connected motor.

Radio interference

[Noise produced by inverters]

Since the VF-S9 series of inverters performs PWM control, it produces noise and sometimes affects nearby instrumental devices, electrical and electronic systems, etc. The effects of noise greatly vary with the noise resistance of each individual device, its wiring condition, the distance between it and the inverter,

[Measures against noises]

According to the route through which noise is transmitted, the noises produced by an inverter are classified into transmission noise, induction noise and

[Examples of protective measures]

Separate the power line from other lines, such as weak-current lines and signal lines, and install them apart from each other.

Install a noise filter in each inverter. It is effective for noise prevention to install noise filters in other devices and systems, as well.


Shield cables and wires with grounded metallic conduits, and cover electronic systems with grounded metallic cases

Separate the power distribution line of the inverter from that of other devices and systems.

Install the input and output cables of the inverter apart from each other. Use shielded twisted pair wires for wiring of the weak-current and signal circuits, and always ground one of each pair of wires.
Ground the inverter with grounding wires as large and short as possible,

separately from other devices and systems.

All models have built-in noise filters which significantly reduce noise.



Power factor improvement capacitors

Do not install a power factor improvement capacitors on the input or output side

Installing a power factor improvement capacitor on the input or output side causes current containing harmonic components to flow into the capacitor, adversely affecting the capacitor itself or causing the inverter to trip. To improve the power factor, install an input AC reactor or a DC reactor (optional) on the primary side of the inverter.

Installation of input AC rectors

These devices are used to improve the input power factor and suppress high harmonic currents and surges. Install an input AC reactor when using a VF-S9 inverter under the following conditions:

- (1) When the power source capacity is 500kVA or more, and when it is 10
- times or more greater than the inverter capacity.

 (2) When the inverter is connected the same power distribution system as a thyristor-committed control equipment.
- (3) When the inverter is connected to the same power distribution system as that of distorted wave-producing systems, such as arc furnaces and large-capacity

Standard replacement intervals of main parts

The table below lists standard component replacement intervals under normal operating conditions (i.e., average year round ambient temperature of 30%C, load ratio of 80% or less, average operation time of 12 hours/day). The replacement intervals do not indicates the service life of each component, but the number of years beyond which the failure rate of a component used without being replaced increases shapely because of deterioration and wear.

Component name	Standard replacement intervals	Replacement method, etc.				
Cooling fan	2 to 3 years	Replaced with a new one				
Smoothing capacitor	5 years	Replaced with a new one (upon examination)				
Circuit breaker, relay		Decided upon examination				
Timer		Decided upon examination of the cumulative operation time				
Fuse	10 years	Replaced with a new one				
Aluminum capacitors on the printed circuit board	5 years	Replaced with a new circuit board (upon examination)				

Extract from "Periodic Inspection of General-purpose Inverters" published by the Japan Electrical Manufacturers' Association

Note: The service life of each component greatly varies with its usage environment

Selecting the capacity (model) of the inverter

Selection

Refer to the applicable motor capacities listed in the standard specifications.

When driving a high-pole motor, special motor, or multiple motors in parallel, select such an inverter that the sum of the motor rated current multiplied by 1.05 to 1.1 is less than the inverter's rated output current value.

Acceleration/deceleration times

The actual acceleration and deceleration times of a motor driven by an inverter are determined by the torque and moment of inertia2 of the load, and can be calculated by the following equations:

The acceleration and deceleration times of an inverter can be set individually. In any case, however, they should be set longer than their respective values determined by the following equations.

Acceleration time	$ta = \frac{(J_M + J_L) \times N}{9.56 \times (T_M - T_L)} \text{ (sec.)}$	
Deceleration time	$ta = \frac{(J_M + J_L)x - N}{9.56 x (T_B + T_L)} \text{ (sec.)}$	
Conditions	Jw: Moment of inertia of motor (kge.m²) J.: Moment of inertia of load (kge.m²) (converted into value on motor shaft) N: Difference in rotating speed between before and after acc. or dee. (min.¹) T.: Load torque (Ne.m) Tw: Motor rated torque x 1.2-1.3 (Ne.m) V/f control: Motor rated torque x 1.7.5 (Ne.m) Vector operation control Ta: Motor rated torque x 0.2 (Ne.m) When a braking resistor or a braking resistor unit is used: Motor rated torque x 0.8-1.0 (Ne.m))

Allowable torque characteristics

When a standard motor is combined with an inverter to perform variable speed operation, the motor temperature rises slightly higher than it normally does during commercial power supply operation. This is because the inverter output voltage has a sinusoidal (approximate) PWM waveform. In addition, the cooling becomes less effective at low speed, so the torque must be reduced according to the frequency. When constant-torque operation must be performed at low speeds, use a Toshiba VF

motor designed specifically for use with inverters.

Starting characteristics

When a motor is driven by an inverter, its operation is restricted by the inverter's overload current rating, so the starting characteristic is different from those obtained from commercial power supply operation.

Although the starting torque is smaller with an inverter than with the commercial power supply, a high starting torque can be produced at low speeds by adjusting the V/f pattern torque boost amount or by employing vector control. (200% in sensorless control mode, though this rate varies with the motor characteristics.) When a larger starting torque is necessary, select an inverter with a larger capacity and examine the possibility of increasing the motor capacity.


Optional external devices

			_							
			No.	Device	Function, Purpose, etc.	Refer t				
			lr	nput AC reactor	Used to improve the input power factor, reduce the harmonics, and suppress external surge on the inverter power source side. Install when the power capacity is 500 kVA or more and 10 times or more than the inverter capacity or when a distorted wave generation source such as a thyristor unit or a large-capacity inverter is connected in the same distribution system.					
		ower supply			Reactor Type Power lactor Improvement 2004-3.7W or less Other model suppression Input AC reactor	P.18				
	× Non	-fuse circuit		C reactor	DC reactor Large x	1.10				
	Mag	iker MCCB inetic actor MC	filter	High-attenuation filter (LC filter) NF type manufactured by Soshin Electric Co.	· ·					
		Input AC reactor (ACL)	Radio noise reduction filter	Zero-phase reactor (inductive filter) Ferrite core type manufactured by Soshin Electric Co.	Effective to prevent interference with audio equipment used near the inverter. Effective in noise reduction on both input and output sides of the inverter. Provided with attenuation characteristics of several dB in frequencies from AM radio bands to 10 MHz. For noise countermeasures, insert on the secondary side of the inverter.	P. 19				
Foot-mounted noise filter	N.F	High-attenuation radio noise filter Zero-phase reactor ferrite core-type radio noise filter	Bag	Foot-mounted type noise reduction filter Soon to be released	High-attenuation EMI noise filter requiring only small space; mounted on the rear side of the inverter. This filter can be installed to conform to the following classes of EMC standard EM5501 Group 1. 3-phase 200 V models excluding those of 5.5/7.5 kW : Conform to Class A. All models other than above : Conform to Class B.					
DC reactor (DCL)			Е	raking resistor	Use when rapid deceleration or stop is frequently required or when it is desired to reduce the deceleration time with large load. This resistor consumes regenerative energy during power generation braking. **Braking resistor - With (resistor + protective thermal relay) built in.	P. 20				
	VF-S9	├	fi	lotor-end surge oltage suppression lter 400 V class only)	Use an insulation-reinforced motor or install the surge voltage restraint filter to prevent degrading motor insulation caused by surge voltage generation depending on cable length and wiring method, or use of a 400 V class motor driven with an inverter.	Contact your				
Purking S		_ =		Conduit pipe kit	Attachment kit used for conformance to NEMA TYPE1.	ur				
Braking resistor			8	P43 enclosure kit	Attachment kit for making a panel conform to the IP43 structure. Available for the 200 V class models of 0.75 kW or less. (Model: DIN0012)					
	N.F	Zero-phase reactor		OIN rail kit oon to be released						
		ferrite core-type radio noise filter	F	arameter writer	Use this unit for batch read, batch copy, and batch writing of setting parameters. (Model: PWU001Z)					
Г		Motor -end surge	E	xtension panel	Extended operation panel kit provided with LED indication section, RUN/STOP key, UP/DOWN key, Monitor key, and Enter key. (Model: RKP001Z)	P. 20				
		voltage suppression filter (for 400V models only)		S485 communication onverter unit	Use to connect a personal computer for data communication with up to 64 units. (Model: RS4001Z)					
/				S232C communication onverter unit	Use to connect a personal computer for data communication. (Model: RS2001Z)					
	IM	Motor	R	lemote panel	Provided with built-in frequency indicator, frequency setting device, and RUN-STOP (forward/reverse) switch. (Model: CBVR-7B1)	P. 2				
				pplication ontrol unit	AP Series is available to enable various types of application control functions when combined with an inverter. Contact your Toshiba representative for further					

Device

External dimensions and connections


Input AC reactor (ACL)



-	B. II				Dime	nsions	Dia a	Tamainala	Approx.weight.				
Туре	Rating	Inverter type	Α	В	C	D	E	F	G	Drawing	Terminals	(kg)	
PFLS2002S	1 -230V-2.0A-50/60Hz	VFS9S-2002PL	80	55	115	63	45	5	45		M3.5	0.85	
PFL2001S	3 -230V-1.7A-50/60Hz	VFS9-2002PM	105	65	115	90	55	5	40		M3.5	1.0	
PFL2005S	3 -230V-5.5A-50/60Hz	VFS9-2004PM,2007PM VFS9S-2004PL,2007PL	105	65	115	90	55	5	40		M3.5	1.2	
PFL2011S	3 -230V-11A-50/60Hz	VFS9-2015PM、2022PM	130	70	140	115	60	5	50	A	M4	2.3	
PFL2018S	3 -230V-18A-50/60Hz	VFS9-2037PM, VFS9S-2015PL,VFS9S-2022PL	130	70	140	115	60	5	50		M4	2.5	
PFL2025S	3 -230V-25A-50/60Hz	VFS9-2055PL	125	100	130	50	83	7			M4	2.6	
PFL2050S	3 -230V-50A-50/60Hz	VFS9-2075PL,VFS9-2110PM	155	115	140	50	95	7			М6	3.4	
PFL2100S	3 -230V-100A-50/60Hz	VFS9-2150PM	230	150	210	60	90	8			M8	8.2	
PFL4012S	3 -460V-12.5A-50/60Hz	VFS9-4007PL~VFS9-4037PL	125	95	130	50	79	7		В		2.3	
PFL4025S	3 -460V-25A-50/60Hz	VFS9-4055PL~VFS9-4110PL	155	110	155	50	94	7			M4	4.9	
PFL4050S	3 -460V-50A-50/60Hz	VFS9-4150PL	155	140	165	50	112	7			M6	6.6	

Note) PFL2002S has 4 terminals

DC reactor (DCL)




Tuna	Rated current	Investor tune			Dime	nsions	(mm)		Drawing	Terminals	Approx.weight.	
Туре	(A)	Inverter type	W	Н	D	Х	Υ	d1	d2	Drawing	Terminais	(kg)
DCLS-2002	2.5	VFS9S-2002PL,VFS9-2002PM	79	50	44	66	_	_	_		V1.25-3.5	0.6
DCL-2007	7	VFS9-2004PM,2007PM VFS9S-2004PL VFS9-4007PL,4015PL Note)	92	65	70	82	_	_	_	A	V2-3.5	1.2
DCL-2022	14	VFS9-2015PM,2022PM VFS9S-2007PL VFS9-4022PL,4037PL Note)	86	110	80	71	64	_	_	В	M4	2.2
DCL-2037	22.5	VFS9-2037PM VFS9S-2015PL,2022PL	86	110	85	71	70	_	55		M4	2.5
DCL-2055	38	VFS9-2055PL	75	130	140	50	85	85	55	С	M5	1.9
DCL-2110	75	VFS9-2075PL~VFS9-2110PM	100	150	150	65	85	95	60		М6	2.4
DCL-2220	150	VFS9-2150PM	117	170	190	90	90	130	_		M8	4.3
DCL-4110	38	VFS9-4055PL~4110PL	95	150	165	70	90	105	60	С	M5	3.0
DCL-4220	75	VFS9-4150PL	105	160	185	80	100	130	65		M8	3.7

Note) VFS9-4007PL~4037PL are used DC reactor for 200V class.

Device

External dimensions and connections


High-attenuation radio noise reduction filter




Туре	Rated current	Inverter type	Dimensions (mm)												Approx.weight.
	(A)	iliverter type	A	В	C	E	F	G	Н	J	K	M	N	Р	(kg)
NF3005A-MJ	5	VFS9-2002PM~VFS9-2007PM													1.0
NF3015A-MJ	15	VFS9-2015PM, VFS9-2022PM	174.5	160	145	110	80	32	70	20	45	ø5.5	M4	l	
NF3020A-MJ	20	VFS9-2037PM												M4	1.6
NF3050A-MJ	50	VFS9-2110PM	267.5	250	235	170	140	44	90		60	ø6.5	M6		4.6
NF3080A-MJ	80	VFS9-2150PM	294.5	280	260	170	150	37	100	30	65	00.5	IVIO	M6	7.0


Note) End of type of Inverter : -PL has a built-in the high-attenuation radio noise reduction filter

Zero-phase ferrite core type radio noise reduction filter



Foot-mounted noise filter Soon to be released






Type	Rated current	Inverter type		Dimensions (mm)		Remarks	
турс	(A)			Н	D	nemarks	
EMFS2010AZ	10			05 185 50		EMC : class B compliance	
EMF2011BZ	11	VFS9-2002PM~2015PM	105		50	EMC : class A compliance	
EMFS2016CZ			205				
EMF4016CZ	. 16 VFS9-4007PL, 4015PL 130			EMC : class B compliance			
EMF2025DZ	25	VFS9S-2022PL	140 2	40 250	60		
EME4005D7	25	VFS9-2022PM, 2037PM				EMC : class A compliance	
EMF4025DZ	25	VFS9-4022PL, 4037PL			60		
EMF4045EZ	45	VFS9-2055PL, 2075PL, VFS9-4055PL, 4075PL	200			EMC : class B compliance	
EMF4045FZ	45	VFS9-4110PL, 4150PL	245	351	51		
EFM2080GZ	80	VFS9-2110PM, 2150PM	240			EMC : class A compliance	

Device

External dimensions and connections

Breaking resistor



Type Rating		Inverter type		Dimensions (mm)					Duamian	Approx.weight.
Туре	nailliy	Inverter type		В	C	C D		G	Drawing	(kg)
PBR-2007	120W-200 Ω	VFS9-2002PM~VFS9-2007PM VFS9S-2002PL~VFS9S-2007PL VFS9-4007PL~VFS9-4022PL Note)								
PBR-2022	120W-75Ω	VFS9-2015PM~VFS9-2022PM VFS9S-2015PL, 2022PL	42 182 2		32 20	4.2	172	_	A&C	0.28
PBR-2037	120W-40Ω	VFS9-2037PM								
PBR3-2055	120W-40Ω×2P (240W-20Ω)	VFS9-2055PL	320		115			50		4
PBR3-2075	220W-30Ω x2P (440W-15Ω)	VFS9-2075PL								4.5
PBR3-2110	220W-30Ω x3P (660W-10Ω)	VFS9-2110PM	120 35		190	110	230	150	B&D	5
PBR3-2150	220W-30Ω ×4P (880W-7.5Ω)	VFS9-2150PM								5.5
PBR-4037	120W-160Ω	VFS9-4037PL	42	182	20	4.2	172	_	A & C	0.28
PBR3-4055	120W-160 Ω×2P (240W-80 Ω)	VFS9-4055PL		320	115			50 150		4
PBR3-4075	220W-120Ω×2P (440W-60Ω)	VFS9-4075PL		350	190		230		B&D	4.5
PBR3-4110	220W-120Ωx3P (660W-40Ω)	VFS9-4110PL	120			110				5
PBR3-4150	120W-120Ω×4P (880W-30Ω)	VFS9-4150PL								5.5

Note) VFS9-4007PL~4022PL are used breaking resister for 200V class.

Parameter writer Extention panel Communication Converter unit (RS485/RS232C)


Parameter writer

Extention panel

Communication Converter Unit


RS485/RS232C

Note) Dimentions of extention panel are same as following drawing, but tha surface of panel are different.




Parameter writer type: PWU001Z Parameter writer cable type: CAB0011(1m) CAB0013(3m) CAB0015(5m)

Extension panel type: PKP001Z Extension panel cable type: CAB0011(1m) CAB0013(3m) CAB0015(5m) Note) Following is RS485 unit. Dimentions of RS232C unit are same as following,but RS232C doesn't have a connector.



RS485 communication converter type: RS4001Z RS485 cable type: CAB0011(1m) CAB0013(3m) CAB0015(5m) RS232C communication converter type: RS2001Z Computer cable type: CAB0025 RS232C cable type: CAB0011(1m) CAB0013(3m) CAB0015(5m)



Trip display / Alarm display

Trip information

Error code	Problem	Remedies
OC 1	Overcurrent during acceleration	Increase the acceleration time FCC. Check the V/F parameter. Use F30 1 (Auto-restart) and F302 (ride-through control).
002	Overcurrent during	Increase the carrier frequency F300 . Increase the deceleration time #EC .
003	deceleration Overcurrent during	• Reduce the load fluctuation.
OCA	operation Arm overcurrent at	Check the load (operated machine). A main circuit element is defective.
	start-up	Make a service call.
OCL	Overcurrent (An overcurrent on the lood side at start-up)	Check the cables and wires for defective insulation.
OP 1	Overvoltage during acceleration	Insert a suitable input reactor. Use F3D 1 (Auto-restart) and F3D2 (ride-through control).
OP2	Overvoltage during deceleration	Increase the deceleration time ⊿EC. Install a suitable dynamic braking resistor. Enable F∃D ∀(dynamic braking selection). Enable F∃D S (overvoltage limit operation). Inset a suitable input reactor.
OP3	Overvoltage during constant-speed operation	Insert a suitable input reactor. Install a dynamic braking resistor.
OL 1	Inverter overload	Increase the acceleration time ACC. Reduce the DC braking amount F25 1 and the DC braking time F252. Check the V/F parameter setting. Use F30 1 (Auto-restart) and F302 (ride-through control). Use an inverter with a larger rating.
0L2	Motor overload	Check the V/F parameter setting. Check the load (operated machine). Adjust □L□ to the overload that the motor can withstand during operation in a low speed range.
ЕРНО	Output phase failure	Check the main circuit output line, motor, etc., for phase failure. Enable F505 (Output phase failure detection).
EPH 1	Input phase failure	Check the main circuit input line for phase failure. Enable FEDB (Input phase failure detection).
DH2	External thermal trip	· Check the external input device.
*0E	Over-torque trip	Check whether the system is in a normal condition.
OLr	Dynamic braking resistor overload trip	Increase the deceleration time JEC . Use a dynamic resistor with a larger capacity (W) and adjust F 3DB (PBR capacity parameter) accordingly.
<i>он</i>	Overheat	Restart the operation by resetting the inverter after it has cooled down enough. The fan requires replacement if it does not rotate during operation. Secure sufficient space around the inverter. Do not place any heat-generating device near the inverter. The thermistor in the unit is broken. Make a service call.
*UP I	Undervoltage trip (main circuit)	Check the input voltage. Enable F527 (undervoltage trip selection). To cope with a momentary stop due to undervoltage, enable F302 (ridethrough control) and (Auto-restart) F30 1.

Trip information

Error code	Problem	Remedies
*UE	Small-current operation trip	• Enable F 10 (Low-current detection parameter). • Check whether the detection level is set properly to the system. (F 11 and F 12) • If no error is found in the setting, make a service call.
EF2	Ground fault trip	Check the cable and the motor for ground faults.
E	Emergency stop	• Reset the inverter.
Errz	Main unit RAM fault	Make a service call.
Err3	Main unit ROM fault	Make a service call.
Erry	CPU fault trip	Make a service call.
Errs	Remote control error	• Check the remote control device, cables, etc.
ELYP	Inverter type error	Make a service call.
EEP!	EEPROM fault	• Turn off the inverter, then turn it on again. If it does not recover from the error, make a service call.
Etn	Auto-tuning error	Check the settings of the motor parameters FYD 1 to FYDB. Check that the motor is not two or more sizes smaller in capacity than the inverter. Check that the inverter output cable is not too thin. Check that the motor is not running. Check that the motor is a three-phase inductive motor.

Note) With a parameter, you can choose between trip-on and -off.

Alarm information

Each message in the table is displayed to give a warning but does not cause the inverter to trip.

Error code	Problem	Remedies				
OFF	ST terminal OFF	· Close the ST-CC circuit.				
noff	Undervoltage in main circuit	Measure the main circuit supply voltage. If the voltage is at a normal level, the inverter requires repairing.				
rErY	Retry in process	The inverter is normal if it restarts after several tens of seconds. The inverter restarts automatically. Be careful of the machine because it may suddenly restart.				
Err 1	Frequency point setting error	• Set the frequency setting signals at points 1 and 2 apart from each other.				
ELr	Clear command acceptable	• Press the STOP key again to clear the trip.				
EOFF	Emergency stop command acceptable	• Press the STOP key for an emergency stop. To cancel the emergency stop, press any other key.				
H 1/L0	Setting error alarm / An error code and data are displayed alternately twice each.	Check whether the setting is made correctly.				
db	DC braking	Normal if the message disappears after several tens of seconds. (See Note.)				
in it	Parameters in the process of initialization	Normal if the message disappears after a while (several seconds to several tens of seconds).				
	Setup parameters in the process of being set	• Normal if the message disappears after a while (several seconds to several tens of seconds).				
REn	Auto-tuning in process	Normal if the message disappears after several seconds.				

Note) When the ON/OFF function is selected for DC braking (DB), using the input terminal selection parameter, you can judge the inverter to be normal if *db* disappears when opening the circuit between the terminal and CC.

To users of our inverters: Our inverters are designed to control the speeds of three-phase induction motors for general industry.

▲ Precautions

- * Read the instruction manual before installing or operating the inverter unit and store it in a safe place for reference.
- * When using our inverters for equipment such as nuclear power control equipment, aviation and space flight control equipment, traffic equipment, and safety equipment, and there is a risk that any failure or malfunction of the inverter could directly endanger human life or cause injury, please contact our headquarters, branch, or office printed on the front and back covers of this catalogue. Such applications must be studied carefully.
- * When using our inverters for critical equipment, even though the inverters are manufactured under strict quality control always fit your equipment with safety devices to prevent serious accident or loss should the inverter fail (such as failure to issue an inverter trouble signal).
- * Do not use our inverters for any load other than three-phase induction motors.

For further information, please contact your nearest Toshiba Representative or International Operations-Producer Goods.

The information in this brochure is subject to change without notice.

In Touch with Tomorrow TOSHIBA

TOSHIBA CORPORATION

Industrial Equipment Department 1-1,Shibaura 1-chome, Minato-ku, Tokyo 105-8001,Japan

Tel.: (03)3457-4900 Fax.: (03)5444-9268

00-8(AB)6491 Printed in Japan